Course: BT 305

Lab Session 5: Analysis of protein structures.

Designed peptides Vs Natural Proteins (Protein G and Trp Cage)

Last date of submission:

Aim: Estimate the solvent accessible surface area (SASA) of the designed peptides as well as Protein G (1PGB.pdb) and Trp Cage (1L2Y.pdb)

Note: Test set: Designed peptides means alpha helix, beta sheet you have designed

Work: 1.Design an alpha helix and beta sheet using PROSS and Ribosome 2. Download 1PGB.pdb and 1L2Y.pdb

The objectives of current session are as follows:

- 1. What is the total relative solvent accessible surface area of the each (total 4) protein/peptide molecule in the test set.
- 2. What is the average per residue solvent accessible surface area of four test proteins.
- 3. Write down all four molecular systems in the increasing order of per residue SASA. What inference would you get from the magnitude of per residue SASA value.
- 4. If you change the probe radius from 1.4 to 1.0, how is it reflected in absolute and relative SASA values.
- 5. In protein G and Trp cage, you will notice that residue TRP has very low values of SASA. What could be the reason?

Materials and methods

Operating System: linux; Computational tool: VADAR